

## N8T Manual Button Programming Instruction

### **1. Enter the Password Menu.**

Press the top key (READ key) and the down key (SEL key), load the battery, and the pager will display the Password menu.

### **2. Enter the Capcode Menu:**

Press the top key (READ key) to move the cursor to right or use down key (SEL key) to change the number. Press up key (EXIT key) to confirm. The default Password is 0000.

### **3. Modify the address code**

Press the SEL key the number will be increased one by one, and press the READ key the program digit will be moved from left to right. If the modification is over, press the EXIT key, if the address capcode is in range, you can change the next capcode, otherwise the pager will ignore it and display the unmodified capcode again.

### **4. Modify the frequency**

Press the SEL key the frequency number will be increased one by one, and press the READ key the program digit will be moved from left to right. If you want to ignore the current change, press the up key (EXIT key).

### **5. Modify the Baudrate**

Press the SEL key to change from 512 to 1200 to 2400, press the READ to confirm.

### **6. Save the program value**

Press the READ key to confirm the setting and the pager will restart.